



WOVEN DESIGN FLOORING

+ INSTALLATION GUIDELINES

- Allow sufficient time to dry out all moisture, when you have no heating system.
- Before and during installation, the temperature must be maintained at 18°C or above at installation site.
- Tile and adhesives must be kept in the installation site for at least 24 hours before installation.
- Prior to installation, check whether tiles are of the same lot number and follow installation guidelines.
- Do not install over plywood or existing PVC flooring.
- Check arrows on the back side of square tiles, and make sure to install them heading all arrows in the same direction.
- Press the floor sufficiently with roller (more than 50kg) after installation.
- Before the sufficient hardening of the adhesives, changes in temperature caused by cooling or heating on the job site can cause instability of the product. This may result in curling up or contraction of the installed tiles.
- When using adhesives, keep the installation site well-ventilated in order to prevent fire or health problems.

+ MAINTENANCE & CAUTION

- All pollutants such as water, grease and dirt, must be removed to avoid slipperiness. Elder, pregnant woman, and children requires extra caution.
- Ventilate the installed site sufficiently after installation in order to reduce the odor of adhesives.
- For heavy stains, mop the floor using soft cloth with neutral detergent or alcohol.
- Do not use strong solvent such as acetone for cleaning.
- For maintenance of the product, please use vacuum cleaner only. Brush can loosen the thread and leave scratches on the tile.